



Planned Maintenance Information

DOME LOADER REGULATORS

SADS ID: SADS/RED/15 SADS/RED/16 SADS/RED/17 SADS/RED18	Serial No: 6638 28619 87624 31264	Item Location: QUAD
Type: Dome Loader	Make: Hale Hamilton	WP: 12 Bar

Ref	Task No.	Maintenance Guide	Frequency
A			6 Monthly
	1	Visual Inspection Dome loader, PRV and all relevant pipe work	
	2	Function Test	
B			2 Yearly
	1	Gas Leak test at MWP for 1 hour check for leaks	
	2	Check Pressure Gauge against master gauge	
	3	Gas Leak test all Pipework at MWP for 1 hour check for leaks	
C			2.5 Yearly
	1	Relief Valve-Function Check at required setting followed by Gas leak test to MWP	
D			5 Yearly
	1	5 yearly service including replacement of seals and seats as per manufactures recommendations	

REMEMBER TO UPDATE ALL RELEVANT FOLDERS

Notes :

1. Provision and Use of Work Equipment Regulations 1998 Apply

WARNING: COMPRESSED GAS. During routine maintenance ensure precautions are taken when using HP/LP gases. Wear all relevant PPE. If unsure DO NOT proceed. Seek advice from experienced personnel.