wing Services (UK) Ltd Planned Maintenance Information

## Depth/Life Support/Indicating Gauges

SADS ID: SADS/DG/ SADS/SG/ SADS/IG/	IMCA D018 Ref: 18, 19, & 20	
---	-----------------------------	--

Ref	Task	Maintenance Guide	Frequency
	No.		
Α	1	General Visual Inspection for damage/corrosion	6 Monthly
	2	Check for accuracy against certified test instrument (DRUCK)	
		<ul> <li>Depth Gauge at 5 points min to 0.25%</li> </ul>	
		- Life Support to minimum of 4 points to 2.5%	
	3	Pressurise & Comparison Check Indicating Gauges	
	4	Ensure all gauges function correctly after calibration	
		equipment is removed	
	5	Put new calibration Sticker or 6M visual sticker by gauge	

## REMEMBER TO FILL IN RELEVANT PAPERWORK/CERTIFICATION & PASS TO DOCUMENT CONTROLLER FOR SCAN & UPLOAD

## Notes :

## 1. Provision and Use of Work Equipment Regulations 1998 Apply

**WARNING: COMPRESSED GAS.** During routine maintenance ensure precautions are taken when using HP/LP gases. Wear all relevant PPE. If unsure DO NOT proceed. Seek advice from experienced personnel.